



MATERIAL:

- ① BRACKET - CSP187-8
- ② TIE MOUNT - PANDUIT TIEWRAP BASE TM3S8
- ③ RIVETS - BLIND RIVET M7885/6-5-2

-1

AS DRAWN

NOTES:

- ① INSTALL TM3S8 PANDUIT TIEWRAP BASES TO BRACKET USING BLIND RIVETS
- 2) THIS BRACKET ASSEMBLY MAY BE USED TO SECURE SIDE HARNESSES WHERE RIVET HEADS DO NOT ALLOW THE INSTALLATION OF TIEWRAP BASE STRAIGHT ONTO THE FRAMES

SEE ENGINEERING STANDARDS APPROVAL RECORD FOR ORIGINAL SIGNATURES AND CHANGE SUMMARY

DRAWN	F. CUZZUPOLI	BRACKET ASSEMBLY, TIEWRAP BASE	CSP480
CHECKED	B. McDONALD		
STRESSED	--		SHEET: 1 OF 1
APPROVED	S. HAMID		

REV:

REV:

REV:

REV:

REV:

REV:

APPROVED: 23 OCT 98