

Signed original on file. Validation of paper prints is the responsibility of the user.

BOMBARDIER

Toronto Site

PROPRIETARY INFORMATION

PPS 25.56

PRODUCTION PROCESS STANDARD

BONDING USING LOCTITE SUPERBONDER 409 AND 430

- Issue 9
- This standard supersedes PPS 25.56, Issue 8.
 - Vertical lines in the left hand margin indicate changes over the previous issue.
 - Direct PPS related questions to christie.chung@aero.bombardier.com or (416) 375-7641.
 - This PPS is effective as of the distribution date.

Prepared By:

(Christie Chung)

January 20, 2015

PPS Group

Approved By:

(K. Quon, for L.K. John)

January 20, 2015

Materials Technology

(A. Assivero, for D. Dawe)

January 22, 2015

Quality

The information, technical data and designs disclosed in this document (the "information") are either the exclusive property of Bombardier Inc. or are subject to the proprietary rights of others. The information is not to be used for design or manufacture or disclosed to others without the express prior written consent of Bombardier Inc. The holder of this document, by its retention and use, agrees to hold the information in confidence. These restrictions do not apply to persons having proprietary rights in the information, to the extent of those rights.

TABLE OF CONTENTS

| Sections | Page |
|--|------|
| 1 SCOPE | 3 |
| 2 HAZARDOUS MATERIALS..... | 3 |
| 3 REFERENCES | 3 |
| 4 MATERIALS AND EQUIPMENT | 3 |
| 4.1 Materials | 3 |
| 4.2 Equipment..... | 4 |
| 5 PROCEDURE | 4 |
| 5.1 General..... | 4 |
| 5.2 Preparation of Parts | 4 |
| 5.3 Bonding..... | 5 |
| 5.4 Curing | 6 |
| 5.5 Sealing | 6 |
| 5.6 Clean-Up..... | 6 |
| 6 REQUIREMENTS | 6 |
| 7 SAFETY PRECAUTIONS | 7 |
| 8 PERSONNEL REQUIREMENTS..... | 7 |
| 9 STORAGE | 7 |
| Tables | |
| TABLE I - PREPARATION OF PARTS FOR ADHESIVE BONDING..... | 5 |
| TABLE II - SEALANT CURE DATA | 6 |

1 SCOPE

- 1.1 This Production Process Standard (PPS) specifies the procedure and requirements for bonding aircraft parts and assemblies with Loctite Superbonder 409 and 430.
 - 1.1.1 This PPS complements the engineering drawings that specify its use as an authorized instruction. The procedure specified in this PPS shall be followed to ensure compliance with all applicable specifications. In general, if this PPS conflicts with the engineering drawing, follow the engineering drawing. The requirements specified in this PPS are necessary to fulfil the engineering design and reliability objectives.
 - 1.1.2 Refer to [PPS 13.26](#) for the subcontractor provisions applicable to this PPS.
 - 1.1.3 Procedure or requirements specified in a Bombardier BAPS, MPS, LES or P. Spec. do not supersede the procedure or requirements specified in this PPS. Similarly, the procedure and requirements specified in this PPS are not applicable when use of a BAPS, MPS, LES or P. Spec. is specified.

2 HAZARDOUS MATERIALS

- 2.1 Before receipt at Bombardier Toronto, all materials shall be approved and assigned Material Safety Data Sheet (MSDS) numbers by the Bombardier Toronto Environment, Health and Safety Department. Refer to the manufacturer's MSDS for specific safety data on any of the materials specified in this PPS. If the MSDS is not available, contact the Bombardier Toronto Environment, Health and Safety Department.

3 REFERENCES

- 3.1 [PPS 13.13](#) - Personal Protective Respiratory Equipment.
- 3.2 [PPS 13.26](#) - General Subcontractor Provisions.
- 3.3 [PPS 13.28](#) - Storage Life of Adhesives, Sealants, Paints and Composite Products.
- 3.4 [PPS 31.17](#) - Solvent Usage.
- 3.5 [PPS 34.08](#) - Application of Epoxy-Polyamide Primer (F19 & F45).

4 MATERIALS AND EQUIPMENT

4.1 Materials

- 4.1.1 Abrasive paper, aluminum oxide, 50 to 80 grit and 120 to 180 grit.
- 4.1.2 DHMS S3.01 Class A Type I sealant.
- 4.1.3 DSC 565-1 adhesive, Loctite Superbonder 409 cyanoacrylate adhesive.

- 4.1.4 Loctite Superbond 430 cyanoacrylate adhesive.
- 4.1.5 Protective coating, PR 1005-L, Products Research.

4.2 Equipment

- 4.2.1 Lint-free cotton gloves (e.g., DSC 422-1).

5 PROCEDURE

5.1 General

- 5.1.1 Loctite Superbond 409 and 430 cannot be used interchangeably. Use the adhesive as specified on the engineering drawing.
- 5.1.2 Loctite Superbond 409 and 430 are fast-setting, room temperature curing, fluid resistant, high strength adhesive.
- 5.1.3 When bonding parts using Superbond adhesive, ensure that the minimum temperature is 60°F (15°C) and the maximum relative humidity is 85%.
- 5.1.4 Take extreme care to avoid skin contact with the adhesive.
- 5.1.5 Use oldest stock of adhesive first.

5.2 Preparation of Parts

- 5.2.1 Wear clean cotton gloves when handling bonding surfaces. Do not touch or contaminate prepared surfaces with bare hands or other foreign objects.
- 5.2.2 Ensure the bonding surfaces of aluminum alloy parts and cadmium plated parts have been primed with F19 according to [PPS 34.08](#).
- 5.2.3 Immediately before applying adhesive, prepare the bond surfaces as specified in [Table I](#).

TABLE I - PREPARATION OF PARTS FOR ADHESIVE BONDING

| MATERIAL | CLEANING PROCEDURE |
|---|---|
| All F19 primed parts | Solvent clean according to PPS 31.17 . |
| Unprimed metal parts | Solvent clean according to PPS 31.17 . |
| Unprimed fibreglass (including Kevlar laminates and composites) | Step 1. Lightly scuff the bonding surfaces with 120 to 180 grit abrasive paper. Step 2. Solvent clean according to PPS 31.17 . |
| Unprimed phenolic (except Formica, Arborite, etc.) | Step 1. Lightly scuff the bonding surfaces with 120 to 180 grit abrasive paper. Step 2. Solvent clean according to PPS 31.17 . |
| Unprimed Formica, Arborite, etc. | Solvent clean according to PPS 31.17 . |
| Unprimed plastic parts (except Kevlar and fibreglass) | Solvent clean according to PPS 31.17 . |
| Rubber parts except silicone (neoprene, Buna-N (nitrile, NBR)) | Solvent clean according to PPS 31.17 . |
| Silicone rubber parts | Step 1. Solvent clean according to PPS 31.17 . Step 2. Lightly scuff the bonding surfaces with 120 to 180 grit abrasive paper. Step 3. Solvent clean according to PPS 31.17 . |
| Wood (except balsa) | Step 1. Sand bond surfaces with 50 to 80 grit abrasive paper. Step 2. Remove residual dust with clean compressed air. |
| Porous materials (Velcro, fabrics, balsa, cork, etc.) | Do not clean porous materials in any way. If the surfaces are contaminated, do not use the materials for bonding. |
| Rulon A | Solvent clean according to PPS 31.17 . |
| Flexible polyurethane foam | Solvent clean according to PPS 31.17 . |
| Rigid polyurethane foam | Step 1. Lightly scuff the bonding surfaces with 120 to 180 grit abrasive paper. Step 2. Remove residual dust with clean compressed air. |

5.3 Bonding

5.3.1 If bonding in a confined area, wear protective respiratory equipment as specified in [PPS 13.13](#).

5.3.2 Perform bonding using Loctite Superbond 409 or 430 as follows:

- Step 1. Apply the adhesive directly from the tube to the bonding surface of one of the parts. Use the adhesive sparingly.
- Step 2. Using the tip of the tube, spread the adhesive over the surface to form a thin, continuous film.
- Step 3. Assemble the parts together in the correct alignment. Do not attempt to re-position the parts after contact has been made.

- Step 4. Apply pressure to ensure intimate contact over the full bonding surface and to distribute the adhesive as thinly as possible in the glue line. Maintain pressure on metal-to-metal bonds for approximately 60 seconds and on metal-to-rubber bonds for approximately 30 seconds.

5.4 Curing

- 5.4.1 Allow the adhesive to cure for 12 hours minimum at 60 to 90°F.

5.5 Sealing

- 5.5.1 Except as specified in [paragraph 5.5.1.1](#), after curing according to [section 5.4](#), seal the exposed glue line on all parts with a thin brush coat of either DHMS S3.01 Class A Type I sealant prepared according to [PPS 21.20](#) or PR 1005-L sealant.

- 5.5.1.1 Unless otherwise specified by the engineering drawing, where the engineering drawing specifies “tack bonding” according to this PPS, sealing as specified herein is not required.

- 5.5.2 Allow the sealant to cure according to [Table II](#).

TABLE II - SEALANT CURE DATA

| SEALANT | SUBSEQUENT PROCESSING | MINIMUM CURE TIME AT 75 ± 2°F, 50% R.H. (Note 1) |
|--|--|--|
| PR 1005-L | Before further handling | 30 minutes |
| | Before further working or installation | 4 hours |
| DHMS S3.01 Type I | Before further handling | according to PPS 21.20 |
| | Before further working or installation | 12 hours for Class A1/2 or 48 hours for Class A2 |
| Note 1. Lower temperature and relative humidity extends cure time. Higher temperature and relative humidity shortens application life. | | |

5.6 Clean-Up

- 5.6.1 Solvent clean uncured adhesive from tools and equipment according to [PPS 31.17](#).
- 5.6.2 Remove excess adhesive from the tube tip before replacing the screw cap.

6 REQUIREMENTS

- 6.1 Bonded parts and assemblies shall have intimate contact over the full bonding area.
- 6.2 Visual indication of poor adhesion is cause for rejection.

- 6.3 Allow bonds to cure for a minimum of 12 hours at 60 to 90°F before being further worked or installed in the aircraft.
- 6.4 Allow sealed parts to cure according to [section 5.5](#) before being further worked or installed in the aircraft.

7 SAFETY PRECAUTIONS

- 7.1 *Observe standard plant safety precautions when performing the procedure specified herein.*
- 7.2 *Always avoid skin contact with the adhesive. If skin contact occurs, immediately wash the affected area with warm water. If fingers become stuck together, immerse bonded area in warm water and pry fingers apart slowly to prevent tearing of skin.*
- 7.3 *Keep adhesive away from fire and other sources of ignition.*
- 7.4 *Ensure sufficient ventilation is supplied when using adhesive in confined areas.*
- 7.5 *Operators sanding parts shall wear protective respiratory equipment according to [PPS 13.13](#).*
- 7.6 *Refer to [PPS 31.17](#) for the safety precautions for handling and using solvents.*

8 PERSONNEL REQUIREMENTS

- 8.1 Personnel responsible for bonding aircraft parts and assemblies using Loctite Superbond 409 or 430 shall have a good working knowledge of the applicable procedure and requirements as specified herein and shall have exhibited their competency to their supervisor.

9 STORAGE

- 9.1 Store Loctite Superbond adhesive at a temperature of 2 to 8°C (36 to 46°F) according to the precautions necessary for flammable materials.
- 9.2 Refer to [PPS 13.28](#) for the storage life of the adhesive.
- 9.3 Ensure adhesive containers are clearly marked with the storage life expiry date.
- 9.4 Keep adhesive containers tightly closed when not in use.